

# Ordering

## ACB & Accessories

Type	Ampere frame	Frame size & phase array	No. of pole	Rated current (CT Spec.)	Connections
AKH	-	3P/4P Standard type RST (N)	3 3P (D)	00 Without OCR & CT	Draw-out type
AKS	06 630AF	D	3 3P (D)	02 200A	J Manual connection
AKN	08 830AF			04 400A	
AKH	10 1000AF	W	4 4P (D, W)	06 630A	A Automatic connection
	13 1250AF			08 800A	
	16 1600AF			10 1000A	
	20 2000AF			13 1250A	
AKS	25 2500AF	W	4 4P (D, W)	16 1600A	M Mixed type Line: Horizontal Load: Vertical
AKS	32 3200AF			20 2000A	
	40 4000AF			25 2500A	
	50 5000AF			32 3200A	
AKS	63 6300AF	Y	4 4P (F, Y)	40 4000A	N Mixed type Line: Vertical Load: Horizontal
	50 5000AF			40 4000A	
AKS	50 5000AF	F	3 3P (F)	50 5000A	P Front type
	63 6300AF			50 5000A	
AKH	40 4000AF	G	3 3P (G)	40 4000A	M Mixed type Line: Horizontal Load: Vertical
	50 5000AF			40 4000A	
AKS	50 5000AF	Z	4 4P (G, Z)	50 5000A	N Mixed type Line: Vertical Load: Horizontal
	63 6300AF			50 5000A	

  

Motor rated voltage	Shunt coil rated voltage	Trip relay
MA Without Motor	D0 Without Shunt coil	Refer to 22 page
M1 AC/DC 100 – 130V	D1 AC/DC 100 – 130V	
M2 AC/DC 200 – 250V	D2 AC/DC 200 – 250V	
M3 DC 125V	D3 DC 125V	
M4 DC 24 – 30V	D4 DC 24 – 30V	
M5 DC 48 – 60V	D5 DC 48 – 60V	
M6 AC 380 – 415V	D6 AC 380 – 480V	
M7 AC 440 – 480V	D7 AC 48V	
M8 AC 48V		

  

Closing coil rated voltage	Closing coil rated voltage	UVT coil rated voltage
D0 Without Closing coil	AX Standard OFF-Charge 3a3b	U0 Without UVT coil
D1 AC/DC 100 – 130V	AC Standard ON-Charge 3a3b	U1 AC/DC 100 – 130V
D2 AC/DC 200 – 250V	BX Standard OFF-Charge 5a5b	U2 AC/DC 200 – 250V
D3 DC 125V	BC Standard ON-Charge 5a5b	U3 DC 125V
D4 DC 24 – 30V	HX High capacity OFF-Charge 5a5b	U4 DC 24 – 30V
D5 DC 48 – 60V	HC High capacity ON-Charge 5a5b	U5 DC 48 – 60V
D6 AC 380 – 480V	CC Standard ON-Charge 6a6b	U6 AC 380 – 480V
D7 AC 48V	JC High capacity ON-Charge 6a6b	U7 AC 48V

  

Accessories		
AL	AL1 + MRB	Trip alarm contact 1a + Manual reset button
A2	AL1 + AL2 + MRB	Trip alarm contact 2a + Manual reset button
A3	AL1 + MRB + RES (AC/DC 100 – 130V)	Trip alarm contact 1a + Manual reset button + Remote reset switch
A4	AL1 + MRB + RES (AC/DC 200 – 250V)	Trip alarm contact 1a + Manual reset button + Remote reset switch
A5	AL1 + MRB + Auto reset	AL + Auto reset type
A6	AL1 + AL2 + MRB + Auto reset	A2+ Auto reset type
A7	AL1 + MRB + RES (AC/DC 100 – 130V) + Auto reset	A3 + Auto reset type
A8	AL1 + MRB + RES (AC/DC 200 – 250V) + Auto reset	A4 + Auto reset type
C	C	Counter
S	CS2	Charge switch communication
B	B	ON/OFF button lock
M	MI	Mechanical Interlock
D	DI or MOC	Door Interlock or Mechanical Operated Cell Switch
K	K1	Key Lock
K2	K2	Key Interlock set
K3	K3	Key Lock double
R	RCS	Ready to close switch
T	TM	Temperature Alarm
H 1)	SHT2	Double Shut Coil

Note) 1. UVT and SHT2 are alternative.  
2. Other accessories should be ordered separately. (Refer to 48 page)